

Prepare pieces for clean insertion. Submerge in 70 percent isopropyl alcohol.

Dry heat takes 1 hour. Never use a steam autoclave.

Proper chemical disinfection preserves the polymer surface and integrity.

CLEAN WITH CHEMICALS ONLY.