

**Leave surface disinfectant wet.
Wait 2 to 10 minutes.
Do not wipe dry prematurely.
Rinse quaternary compounds with 70 percent alcohol.**



**Pathogens survive on prematurely dried procedure surfaces.
WAIT FOR FULL CHEMICAL KILL.**