

- **First: Separate all dirty tools immediately.**
- **Second: Soak in 1 percent enzymatic detergent.**
- ▲ **Third: Keep water below 55 degrees Celsius.**
- **Fourth: Rinse thoroughly and inspect visually.**

Excess heat destroys the active enzymes needed for cleaning.
NEVER AUTOCLAVE DIRTY INSTRUMENTS