

1 Verify material mill certificates upon initial delivery.

2 Confirm titanium meets the exact implant standard.

3 Check that gold is nickel and cadmium free.

4 Inspect all surfaces for scratches and burrs.

Fresh body piercings take between 6 weeks and 9 months to heal.
FOLLOW STRICT AFTERCARE PROTOCOLS EVERY TIME.