



**Prep skin with approved antiseptic.
Mark exact point with single marker.
Create pocket at 90 degree angle.
Insert base with sterile forceps.**

**The subcutaneous pocket must fit the base snugly.
SCREW TOP UNTIL FINGER TIGHT.**