



Step 1 removes the transparent protective paper.

Step 2 tears off the yellow backing.

Step 3 inserts the purple carbon face down.

Step 4 transfers the digital design wirelessly.

**Correct paper alignment guarantees a crisp outline.
FOLLOW PRECISE LOADING STEPS FOR PERFECT TRANSFERS**