Always remove the protective middle sheet.

Never feed misaligned paper into the rollers.

Trapped moisture destroys the stencil carbon layer.

Crooked loading causes severely wrinkled transfer sheets.

Removing the brown middle sheet prevents jams.

PROPER TENSION CREATES A FLAWLESS FLAT STENCIL

Gemini Notebook