Stop processing all instruments immediately.

Identify window and segregate affected inventory.

Check the unsterilized control vial.

Run consecutive passing spore tests.

3

A positive spore test is a confirmed sterilization breach requiring immediate action.

LOCK DOWN THE AUTOCLAVE