

DO place pouches on edge.
DO leave space between packs.



Instruments packed too tightly prevent essential steam penetration during the sterilization cycle.

LOAD POUCHES ON THEIR EDGE

DO NOT pack instruments flat.
DO NOT overload the chamber.



Instruments packed too tightly prevent essential steam penetration during the sterilization cycle.

LOAD POUCHES ON THEIR EDGE