
Precondition load humidity.	1
Admit ethylene oxide.	6
Maintain chemical concentration.	
Aerate residual toxins.	

Ethylene oxide sterilization requires careful humidity control and continuous gas exposure.
Mandatory aeration strictly removes all dangerous chemical residues.