

	Step 1	removes gross debris.
	Step 2	reduces surface microorganisms.
	Step 3	requires an autoclave.
	Complete sequence in exact order.	

Gremnart moriane somicoigner map the tunche micnomatiam.

Pressurized steam is the most practical method.

NEVER REUSE DISPOSABLE NEEDLES.