

Verify autoclave sterility indicators.



Examine apex under a 10x loupe.

Handle instruments by the body exclusively.

Recap using the 1-hand scoop method.

**Strict handling prevents accidental bloodborne pathogen exposure.
NEVER TOUCH THE NEEDLE TAPER OR APEX.**