6 give settings adjust electronic resistance.
Level 0 delivers the hardest hit.
Level 5 delivers the softest hit.
Adjust parameters via the battery menu.

Give controls needle resistance upon impact with the skin.

CONTROL NEEDLE IMPACT ELECTRONICALLY

Gemini Notebook